

Accessories and Spare Parts for Banks

Classification table

Ref.	Application						
	Identify the dwelling corresponding to emeter						
	Dimensions						
	Billets	Rows	Height (cm)	Width (cm)			
	4	2	16	12			
	6	2	18	18			
	6	3	21	12			
	8	2	18	24			
	9	3	18	22			
	10	2	18	29			
	12	2	17	35			
	12	3	22	24			
	14	2	17	41			
	15	3	22	29			
BH006	16	2	17	47			
Diloco	18	2	17	52			
	18	3	21	35			
	20	2	17	58			
	21	3	21	41			
	22	2	17	64			
	24	2	17	70			
	24	3	21	47			
	26	2	17	75			
	27	3	21	52			
	28	2	17	81			
	30	2	17	87			
	30	3	21	58			
	33	3	21	65			
	36	3	21	70			
	39	3	21	75			
	42	3	21	81			
	45	3	21	87			

The board is manufactured in 1mm thick anodised aluminium (anticorrosive).


Wall installation above bank of meters using the four screws and plugs supplied with the board.




Blind flange

Ref.	Application
ВН007	Cancel the surplus bank billets

8-mm thick bichromated steel flange. It is supplied with seal and two screws with DACROMET + PLUS protection against corrosion.






Telf.: +34 902 760 987

Standard pipe

_	Applio	cation		
Ref.	Increase meter bank distribution capacity by one billet			
	Galvanised steel	Stainless steel		
вноов	•			
вн030		•		

It can be installed over either of the two lateral ends of the upper bank bridge using the four screws supplied with the pipe, without forgetting the two joint seals between the connection billets.



Ref.	H (mm)	L (mm)	D	Weight (kg)
BH008	00	258	1 "	1,70
BH030	98		1	1,20

Male/female Flexo

Ref.	Application Connect the meter exit valve to the fresh water stanchion				
	L (mm)	Male connection thread		Female connection thread	
		3/4"	1"	3/4"	1"
BH014	400	•		•	
	F00	•		•	
	500		•		•
Contact u	ıs for ot	her lengths	and thread	ds.	



Flexo consisting of an interior EPDM rubber pipe, AISI stainless steel braid, nickel-plated brass connection threads and AISI 304 stainless steel pressure bushing.






Accessories and Spare Parts for Banks


Check valve

Ref.	Application							
	To prevent the return of undesired bank water to the water mains system.							
BH012	PN	Dimensions			Dimensions			
	16	1 1/2"	2"	2 1/2"	3″			
	16	•	•	•	•			

Dimension	A (mm)	H (mm)	D (mm)
1 1/2"	105,5	117,5	36
2″	110	115	50
2 1/2"	130	121	60
3"	150	140	74
	1 ½" 2" 2 ½"	1 ½" 105,5 2" 110 2 ½" 130	Dimension (mm) (mm) 1 ½" 105,5 117,5 2" 110 115 2 ½" 130 121








Ship flange


Ref.	Application				
	Connect	Connect the service valve to the bank with the feed pipe.			
BH011	PN	Dime	nsions		
	10	1 1/2"	2"		
	10	•	•		




Bana flange

Ref.	Application							
	Connec	Connect the service valve to the bank with the feed pipe.						
BH010	PN	Dimensions				Dimensions		
	10	60/ 2 1/2"	80 /3"	100 / 4"				
	10	•	•	•				

D-6	DN	d1	d2	d3	d4	ь	No	
Ref.	DN	a 1		(m	m)		drill holes	
	60	2 1/2"	188	18	145	19	4	A
BH010	80	3″	200	18	160	21	8	
	100	4"	220	18	180	22	8	
			_					







DIN 2573 flange

Ref.	Application					
	Connect the feed pipe to the bank.					
ВН009	PN	Dimensions				
	_	1 1/2"	2″	2 1/2"	3″	
	6	•	•	•	•	

Ref. DN		d2	d3	d4	b	No	
	DN	DN d1	(mm)				drill holes
40 50 BH009	40	1 1/2"	130	14	100	16	4
	50	2"	140	14	110	16	4
БПООЭ	60 2 1/2"	2 1/2"	160	14	130	16	4
	80	3″	190	18	150	18	4



